



20° angle
drilling
template

This edge
mounts to
1/2" dowel
(insert the
dowel into
expended
engine
casing)



1" reference line